

Operating and Health and Safety Instructions for use with the Dinbite Din Rail Cutting Machine

Please take a few moments to read these basic safety instructions:

Usage:

- The **Dinbite** din rail guillotine is designed to cut standard top hat 7.5mm x 35mm only.
- It will only cut plain and slotted Steel or Aluminium Din Rail.
- Do not cut any other items or materials. You can damage the **Dinbite** and possibly break the blades.
- Do not cut bolts or other items as the blades may break.
- Remove the cut sections regularly. Not removing these rejected sections can cause the machine to jam and break the blades.
- Keep lightly lubricated, 'WD 40' is a recommend lubricant.


Personal Safety:

- It is advised that when using a **Dinbite** din rail guillotine that safety gloves, spectacles or goggles are worn.
- Keep fingers and clothing away from the **Dinbite** cutting blade and mechanism whilst cutting rail.
- Be aware of others when handling din rail as it can cause injury.
- Follow the mounting instructions when using in a vice or fixing to a bench (see below)
- Keep the area around the **Dinbite** clean and tidy

Environmental:

- The **Dinbite** is 100% recyclable
- Your **Dinbite** can be repaired and restored when required
- All components of the **Dinbite** are available as spare parts or a rebuild service is available
- Spare blades are available when required


Mounting Instructions:



Incorrect



Correct



Oil Occasionally

When mounting **Dinbite** onto a bench or work surface, ensure that the waste pieces removed are able to clear the tool. We suggest drilling a 50mm hole under the **Dinbite**. If mounting in a vice this is not required.